



VB5 Neoprene Gasketing Foam

Tools Required for Installation:

- Tape measure
- Scissors or box knife
- Straight edge ruler

Materials Required for Surface Preparation:

- Warm, soapy water
- Aerosol glass cleaner (i.e. Sprayway)

Applications

- Interior trim panels
- Linkages
- Harnesses
- Speakers

Important Install Tips

- 1) A little VB5 will go a long way! Only small pieces of this materials are necessary to prevent squeaks, rattles and buzzes from occurring.
- 2) Take a moment to measure the surface to be treated to make sure enough material is available to complete the installation.
- 3) No heat is required to install the VB5 product.

Coverage

- 1) A small piece of material should be enough to eliminate potential noise.

Installation

- 1) Begin by measuring twice, cutting and fitting the material to be installed first.
- 2) Make sure the installation of this product will not impede the proper operation of any mechanical component.
- 3) Clean the surface to be treated by washing with warm, soapy water to remove dirt and debris then dry with a clean towel. Follow up by cleaning the surface a final time with an aerosol glass cleaner (i.e. Sprayway) to remove oil, wax and grease that may still be present.
- 4) Remove the paper release liner and apply the VB5 product onto the surface.

Contact Information:

Cascade Audio Engineering
64894 Old Bend Redmond Hwy
Bend, Oregon 97701
Phone / 541-389-6821
Fax / 541-389-5273
Email / sales@cascadeaudio.com
Web / www.cascadeaudio.com

