



INSULATOR 12

Installation:

Preparation:

- Be sure to clean the surface of automotive body panels by washing thoroughly with warm, soapy water to remove any dirt or dust particles.
- For best results, take measurements of area to be treated prior to any modification of Insulator sheet.

Installation:

- Cut the Insulator sheet to fit the area to be treated. The Insulator may be cut with either scissors or a razor knife.
- Apply with Sticky-Stuff Spray Adhesive (™). For best results, use Insul-Tape (™) to seal seams and insure vapor barrier.
- Complete the installation by removing excess material that would interfere with normal operation of any hinges or latching mechanisms.



Tech Tip:

The Insulator is extremely effective as a radiant heat barrier. Install on firewall, headliner, and around transmission tunnel to maintain a cooler, quieter interior

TOOLS:

Tape measure
Scissors or razor knife



CASCADE AUDIO ENGINEERING

PH: 541-389-6821 - FX: 541-389-5273

sales@cascadeaudio.com

www.cascadeaudio.com