



## VB-TS / VB-TSXL Installation:

### Preparation:

- Be sure to clean the surface of automotive body panels by washing thoroughly with warm, soapy water to remove any dirt or dust particles.
- CAE recommends cleaning the surface once more with an ammonia based, aerosol glass cleaner to remove unwanted wax and grease.
- For best results, take measurements of area to be treated prior to any modification of VB-TS roll.

### Installation:

- Cut the VB-TS roll to fit the panel to be treated. VB-TS may be cut with either scissors or a razor knife. Remove the release liner and apply to the prepared surface. For larger surfaces, pull release liner down about 6 inches and apply to surface in 6 to 8 inch increments.
- Complete the installation by removing excess material that would interfere with normal operation of any hinges or latching mechanisms.



### ***Tech Tip:***

When VB-TS is being used in an underhood application, it is most effective when adhered to the outer edge and structural ribbing only.

### ***TOOLS:***

Tape measure  
Scissors or razor knife

  
CASCADE AUDIO ENGINEERING  
PH: 541-389-6821 - FX: 541-389-5273  
sales@cascadeaudio.com  
www.cascadeaudio.com

### Please Note:

Product must be installed within one year for best performance.