



V-MAX

Installation:

Preparation:

- Be sure to clean the surface of automotive body panels by washing thoroughly with warm, soapy water to remove any dirt or dust particles. CAE recommends cleaning the surface once more with an ammonia based, aerosol glass cleaner to remove unwanted wax and grease.

Installation:

- Cut the **VMAX** damping sheet to fit the panel to be treated. The material can be cut with scissors or a razor knife. Remove the release liner and apply to the prepared surface. Apply pressure to damping sheet with fingers to ensure good contact to substrate. For larger surfaces, pull release liner down about 6 inches and apply to surface. Keep working the material down the panel in 6 to 8 inch increments until full adhesion has been achieved.

Tech Tip:

- 50% coverage will yield good damping, however 75% to 100% coverage will maximize the effects of the product.



TOOLS:

Scissors or a razor knife



CASCADE AUDIO ENGINEERING

PH: 541-389-6821 - FX: 541-389-5273

sales@cascadeaudio.com

www.cascadeaudio.com

Please Note:

Product must be installed within one year for best performance.